


# Before you Add Accessories !

This C2 is equipped with an accessory power supply module under the driver's left switch panel.



Fuses must be installed in the blocks before the lugs are energized. The upper 4 are ignition activated. The lower four are always activated.